



MODELL					
STL	SBVR	SBVK	SBNR	SBNK	$L_2$
800				0574594	780
900	0563580	0563584	0563590	0563594	880

Justermån/Justeringsmål/Adjustment:  $L_2 \pm 10$  mm